



405 South Arch St.
Janesville, WI 53548

Phone: 608-752-6507
Toll Free: 1-888-222-4541
Fax: 608-752-5671

Window Well Recommended Site Preparation

- Dimensions of Window Well are 81” x 42” x 72” tall.
- Excavation should be done in order to leave 12” of space around the window well.
- Excavation should be done deep enough to get well in.
- Would like to coordinate window well delivery and install before waterproofing and insulation are installed.
- Foundation wall should be fully cured before installation.